



**Basic MIDI setup**  
 5-pin midi on back  
 Patch MIDI/CV  
 PITCH to PITCH CV IN  
 GATE OUT 1 to GATE 1

**INIT sound**  
 Set knobs to indicated positions

**ENV 1 & 2 not triggering?**  
 LED cables takes some voltage, so don't use them from GATE booster out.

**Basic CV/GATE setup**  
 PITCH CV IN  
 GATE

**Normalized Gates**  
 GATE 1 triggers GATE 2 and GATE 3  
 Inserting a plug breaks the connection.

